



Polycase Knockout Instructions

SK Series Enclosures

Attention! Wear safety glasses and take proper safety precautions when using tools.

1. Place a **flathead screw driver** into the slot of the knockout that is to be removed. The screw driver must be placed in the slot toward the **BOTTOM/CLOSED END** of the enclosure (opposite the cover).



2. Hit the end of the screw driver to shear the knockout and remove the rest of the knockout by hand if necessary.
3. If burrs remain, remove them with a countersink or deburring tool.